

# ETHAN ALLEN®

## SMALL MINETTO WOOD PENDANT CHANDELIER/PENDANT LAMP

### ASSEMBLY INSTRUCTIONS

09-0536

#### IMPORTANT SAFETY INSTRUCTIONS. READ THESE INSTRUCTIONS COMPLETELY BEFORE STARTING.

We strongly recommend that all direct-wired lighting products be installed by a licensed electrician. Two people may be required for installation. DO NOT EXCEED the rated bulb wattage. Keep flammable materials away from bulbs. This light fixture is shipped with all internal wiring intact. Do not open the product or alter the wiring in any manner.

Installation requires an electrical junction box in the ceiling sufficient to support the weight of the light fixture. This fixture weighs: 32.67 lbs. (14.82 kg).



**WARNING:** Be certain that the power to the electrical junction box is turned off at the circuit breaker before installation. Turning the power off at a light switch is not sufficient to prevent electrical shock.

CAUTION: Prior to installation, locate All INCLUDED PARTS before disposing of packaging materials.

#### TOOLS REQUIRED FOR INSTALLATION


|                 |                   |
|-----------------|-------------------|
| Screwdrivers    | Pliers            |
| Electrical Tape | Wire Connectors   |
| Wire Cutters    | Adjustable Wrench |

Note: Lightbulb(s) are not included, except where required by State of California Title 20. See light fixture for bulb specification. Additional wiring supplies may be required.

#### PARTS INCLUDED (See Figure 1):

| Part | Qty. | Description       |
|------|------|-------------------|
| A    | 1    | Cable             |
| B    | 1    | Canopy            |
| C    | 4    | Bulb holder (E12) |
| D    | 1    | Lamp Base         |

Figure 1



#### Installation Procedure (See Figure 1)

1. Drill at the ceiling to make a hole to match with the hook.
2. Screw the hook with the hole and ensure it is attached with the ceiling tightly.
3. Hang the chandelier with the hook.
4. Connect the household cable with the Chandelier's Cable (A).
5. Connect the cable (A) to each pole. Remember the current for the product is 3A maximum.
6. Move the canopy (B) up to the ceiling and screw to lock it.

#### CARE AND CLEANING:

To clean, wipe the light fixture ONLY with a soft dry cloth.

In the event that the light fixture does not work, contact your local Ethan Allen Design Center.