

ETHAN ALLEN®

Reena Buffet Lamp Assembly Instructions

096156

IMPORTANT SAFETY INSTRUCTIONS

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, AND PERSONAL INJURY:

This lighting fixture is for indoor use only. This lamp is equipped with a polarized plug. One plug blade is wider than the other. DO NOT MODIFY the plug or power cord in any way. DO NOT EXCEED the recommended bulb wattage. Use only the type of bulb specified. Keep flammable materials away from bulb. DO NOT OPEN the product or alter the wiring in any manner. Extension cord: follow precautions provided with power cord.

Use care when unpacking. Locate ALL PARTS INCLUDED before disposing of packaging materials.

Caution: To avoid fingerprint on the lamp body, one pair of gloves is attached in packaging for your convenience to hold the lamp.

ASSEMBLY, CARE, AND TROUBLESHOOTING

No tools required for assembly. Light bulb is not included.

Parts Included: (Refer to Figure)

- A. Finial
- B. Shade
- C. Pipe
- D. Distributor
- E. Socket
- F. Plug Cap

Assembly Procedure: (Refer to Figure)


1. Install Pipe Part (C) into Distributor (D)
2. Install Shade (B) onto Pipe (C)
3. Install finial (A) into Pipe (C)
4. Install bulb into Socket (E)
5. Remove Plug Cap (F)

Caring for and cleaning your lamp:

1. Wipe with a soft, dry cloth.
2. Avoid cleaners, scouring pads, etc.
3. Before changing bulb, unplug lamp and allow bulb to cool.

Troubleshooting:

Problem:	Possible cause:	Correction:
Bulb does not light	Bulb is burnt out or damaged	Replace bulb
	Power to lamp is off	Confirm power is on
	Lamp is not plugged in	Confirm lamp is plugged in



After troubleshooting if the lighting fixture still does not work, contact your local Ethan Allen Design Center.

SAVE THESE INSTRUCTIONS